

Link do produktu: <https://www.moto-maniak.eu/czujnik-wentylatora-chlodnicy-arctic-cat-500-650-700-0413-045-0413-168-p-11586.html>



czujnik wentylatora chłodnicy Arctic cat 500 650 700 0413-045, 0413-168

Cena brutto	85,00 zł
Cena netto	69,11 zł
Dostępność	Niedostępny
Numer katalogowy	CAL-SR120
Kod EAN	5904858403172
Producent	X-ATV

Opis produktu

czujnik załączania wentylatora

zamiennik oem arctic cat: 0413-045, 0413-168

zastosowanie :

2002 400 2x4 MANUAL TRANSMISSION FIS (GREEN) (A2002ISI2AUSG) - Cooling Assembly
 2002 400 2x4 MANUAL TRANSMISSION FIS (RED) (A2002ISI2AUSR) - Cooling Assembly
 2002 400 4X4 MANUAL TRANSMISSION (RED) (A2002ATI4AUSR) - Cooling Assembly
 2002 400 4X4/500 MANUAL TRANSMISSION (500 GREEN) (A2002ATM4AUSG) - Cooling Assembly
 2002 400 4X4/500 MANUAL TRANSMISSION (500 RED) (A2002ATM4AUSR) - Cooling Assembly
 2002 400 4x4 MANUAL TRANSMISSION (GREEN) (A2002ATI4AUSG) - Cooling Assembly
 2002 400 4x4 MANUAL TRANSMISSION FIS (GREEN) (A2002ISI4AUSG) - Cooling Assembly
 2002 400 4x4 MANUAL TRANSMISSION FIS (RED) (A2002ISI4AUSR) - Cooling Assembly
 2002 400/500 MANUAL TRANSMISSION FIS (500 GREEN) (A2002ISM4AUSG) - Cooling Assembly
 2002 400/500 MANUAL TRANSMISSION FIS (500 RED) (A2002ISM4AUSR) - Cooling Assembly
 2002 500 AUTOMATIC TRANSMISSION (GREEN) (A2002ATM4BUSG) - Cooling Assembly
 2002 500 AUTOMATIC TRANSMISSION (RED) (A2002ATM4BUSR) - Cooling Assembly
 2002 500 AUTOMATIC TRANSMISSION FIS (GREEN) (A2002ISM4BUSG) - Cooling Assembly
 2002 500 AUTOMATIC TRANSMISSION FIS (RED) (A2002ISM4BUSR) - Cooling Assembly
 2002 500 AUTOMATIC TRANSMISSION TBX (A2002BXM4BUSG) - Cooling Assembly
 2003 500 FIS AUTOMATIC TRANSMISSION (CAT GREEN) (A2003ISM4BUSZ) - Cooling Assembly
 2003 500 FIS AUTOMATIC TRANSMISSION (GREEN - MRP) (A2003ISM4BUSS) - Cooling Assembly
 2003 500 FIS AUTOMATIC TRANSMISSION (GREEN) (A2003ISM4BUSG) - Cooling Assembly
 2003 500 FIS AUTOMATIC TRANSMISSION (RED) (A2003ISM4BUSR) - Cooling Assembly
 2003 500 FIS MANUAL TRANSMISSION (GREEN - MRP) (A2003ISM4AUSS) - Cooling Assembly
 2003 500 FIS MANUAL TRANSMISSION (GREEN) (A2003ISM4AUSG) - Cooling Assembly
 2003 500 FIS MANUAL TRANSMISSION (RED) (A2003ISM4AUSR) - Cooling Assembly
 2003 500 TBX (A2003BXM4BUSG) - Cooling Assembly
 2003 500 TRV AUTOMATIC TRANSMISSION (A2003TDM4BUSG) - Cooling Assembly
 2004 500 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2004ISM4BUSZ) - Cooling Assembly
 2004 500 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN MRP (A2004ISM4BUSV) - Cooling Assembly
 2004 500 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2004ISM4BUSG) - Cooling Assembly
 2004 500 AUTOMATIC TRANSMISSION 4X4 FIS GREEN MRP (A2004ISM4BUSS) - Cooling Assembly
 2004 500 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2004ISM4BUSR) - Cooling Assembly
 2004 500 AUTOMATIC TRANSMISSION 4X4 FIS RED MRP (A2004ISM4BUST) - Cooling Assembly
 2004 500 AUTOMATIC TRANSMISSION 4X4 TBX GREEN (A2004BXM4BUSG) - Cooling Assembly
 2004 500 AUTOMATIC TRANSMISSION 4X4 TBX RED (A2004BXM4BUSR) - Cooling Assembly
 2004 500 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2004TDM4BUSZ) - Cooling Assembly
 2004 500 AUTOMATIC TRANSMISSION 4X4 TRV GREEN (A2004TDM4BUSG) - Cooling Assembly
 2004 500 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2004TDM4BUSR) - Cooling Assembly
 2004 500 MANUAL TRANSMISSION 4X4 FIS CAT GREEN (A2004ISM4AUSZ) - Cooling Assembly
 2004 500 MANUAL TRANSMISSION 4X4 FIS CAT GREEN MRP (A2004ISM4AUSV) - Cooling Assembly

2004 500 MANUAL TRANSMISSION 4X4 FIS GREEN (A2004ISM4AUSG) - Cooling Assembly
2004 500 MANUAL TRANSMISSION 4X4 FIS GREEN MRP (A2004ISM4AUSS) - Cooling Assembly
2004 500 MANUAL TRANSMISSION 4X4 FIS RED (A2004ISM4AUSR) - Cooling Assembly
2004 500 MANUAL TRANSMISSION 4X4 FIS RED MRP (A2004ISM4AUST) - Cooling Assembly
2004 650 V-2 4X4 FIS CAT GREEN (A2004ISR4BUSZ) - Cooling Assembly
2004 650 V-2 4X4 FIS CAT GREEN CA (A2004ISR4BCAZ) - Cooling Assembly
2004 650 V-2 4X4 FIS CAT GREEN MRP (A2004ISR4BUSV) - Cooling Assembly
2004 650 V-2 4X4 FIS CAT GREEN MRP CA (A2004ISR4BCAV) - Cooling Assembly
2004 650 V-2 4X4 FIS CAT GREEN MRP NA (A2004ISR4BNAV) - Cooling Assembly
2004 650 V-2 4X4 FIS CAT GREEN SE (A2004ISR4BUSA) - Cooling Assembly
2004 650 V-2 4X4 FIS CAT GREEN SE CA (A2004ISR4BCAA) - Cooling Assembly
2004 650 V-2 4X4 FIS CAT GREEN SE NA (A2004ISR4BNAA) - Cooling Assembly
2004 650 V-2 4X4 FIS GREEN (A2004ISR4BUSG) - Cooling Assembly
2004 650 V-2 4X4 FIS GREEN CA (A2004ISR4BCAG) - Cooling Assembly
2004 650 V-2 4X4 FIS GREEN MRP (A2004ISR4BUSS) - Cooling Assembly
2004 650 V-2 4X4 FIS GREEN MRP CA (A2004ISR4BCAS) - Cooling Assembly
2004 650 V-2 4X4 FIS GREEN MRP NA (A2004ISR4BNAS) - Cooling Assembly
2004 650 V-2 4X4 FIS RED (A2004ISR4BUSR) - Cooling Assembly
2004 650 V-2 4X4 FIS RED CA (A2004ISR4BCAR) - Cooling Assembly
2004 650 V-2 4X4 FIS RED MRP (A2004ISR4BUST) - Cooling Assembly
2004 650 V-2 4X4 FIS RED MRP CA (A2004ISR4BCAT) - Cooling Assembly
2004 650 V-2 4X4 FIS RED MRP NA (A2004ISR4BNAT) - Cooling Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2005IBM4BUSZ) - Cooling Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2005IBM4BUSG) - Cooling Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 FIS LE CAT GREEN (A2005IBM4BUSA) - Cooling Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 FIS LE GREEN (A2005IBM4BUSM) - Cooling Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 FIS LE RED (A2005IBM4BUSN) - Cooling Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2005IBM4BUSR) - Cooling Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 TBX GREEN (A2005BBM4BUSG) - Cooling Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 TBX RED (A2005BBM4BUSR) - Cooling Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2005TDM4BUSZ) - Cooling Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 TRV GREEN (A2005TDM4BUSG) - Cooling Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2005TDM4BUSR) - Cooling Assembly
2005 500 MANUAL TRANSMISSION 4X4 FIS CAT GREEN (A2005IBM4AUSZ) - Cooling Assembly
2005 500 MANUAL TRANSMISSION 4X4 FIS GREEN (A2005IBM4AUSG) - Cooling Assembly
2005 500 MANUAL TRANSMISSION 4X4 FIS RED (A2005IBM4AUSR) - Cooling Assembly
2005 650 H1 4X4 BLACK LE (A2005IBS4BUSO) - Cooling Assembly
2005 650 V-2 4X4 FIS CAT GREEN (A2005IBR4BUSZ) - Cooling Assembly
2005 650 V-2 4X4 FIS CAT GREEN CA (A2005IBR4BCAZ) - Cooling Assembly
2005 650 V-2 4X4 FIS CAT GREEN LE (A2005IBR4BUSA) - Cooling Assembly
2005 650 V-2 4X4 FIS CAT GREEN LE CA (A2005IBR4BCAA) - Cooling Assembly
2005 650 V-2 4X4 FIS GREEN (A2005IBR4BUSG) - Cooling Assembly
2005 650 V-2 4X4 FIS GREEN CA (A2005IBR4BCAG) - Cooling Assembly
2005 650 V-2 4X4 FIS GREEN LE (A2005IBR4BUSM) - Cooling Assembly
2005 650 V-2 4X4 FIS GREEN LE CA (A2005IBR4BCAM) - Cooling Assembly
2005 650 V-2 4X4 FIS RED (A2005IBR4BUSR) - Cooling Assembly
2005 650 V-2 4X4 FIS RED CA (A2005IBR4BCAR) - Cooling Assembly
2005 650 V-2 4X4 FIS RED LE (A2005IBR4BUSN) - Cooling Assembly
2005 650 V-2 4X4 FIS RED LE CA (A2005IBR4BCAN) - Cooling Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2006IBM4BUSZ) - Cooling Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2006IBM4BUSG) - Cooling Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2006IBM4BUSC) - Cooling Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2006IBM4BUSR) - Cooling Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 FIS RED LE (A2006IBM4BUSN) - Cooling Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 TBX GREEN (A2006BBM4BUSG) - Cooling Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 TBX RED (A2006BBM4BUSR) - Cooling Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2006TBM4BUSZ) - Cooling Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 TRV GREEN (A2006TBM4BUSG) - Cooling Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2006TBM4BUSR) - Cooling Assembly
2006 500 MANUAL TRANSMISSION 4X4 FIS CAT GREEN (A2006IBM4AUSZ) - Cooling Assembly
2006 500 MANUAL TRANSMISSION 4X4 FIS GREEN (A2006IBM4AUSG) - Cooling Assembly
2006 500 MANUAL TRANSMISSION 4X4 FIS RED (A2006IBM4AUSR) - Cooling Assembly
2006 650 H1 AUTOMATIC TRANSMISSION 4X4 BLACK SE (A2006IBS4BUSO) - Cooling Assembly
2006 650 H1 AUTOMATIC TRANSMISSION 4X4 BLACK SE CA (A2006IBS4BCAO) - Cooling Assembly
2006 650 V-TWIN AUTOMATIC TRANSMISSION 4X4 FIS GREEN CA (A2006IBR4BCAG) - Cooling Assembly
2006 650 V-TWIN AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2006IBR4BUSZ) - Cooling Assembly
2006 650 V-TWIN AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN CA (A2006IBR4BCAZ) - Cooling Assembly
2006 650 V-TWIN AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2006IBR4BUSG) - Cooling Assembly
2006 650 V-TWIN AUTOMATIC TRANSMISSION 4X4 FIS RED (A2006IBR4BUSR) - Cooling Assembly

2006 650 V-TWIN AUTOMATIC TRANSMISSION 4X4 FIS RED CA (A2006IBR4BCAR) - Cooling Assembly
2006 650 V-TWIN AUTOMATIC TRANSMISSION 4X4 FIS TONY STEWART EDITION (A2006IBR4BUSX) - Cooling Assembly
2006 650 V-TWIN AUTOMATIC TRANSMISSION 4X4 FIS TONY STEWART EDITION CA (A2006IBR4BCAX) - Cooling Assembly
2006 700 AUTOMATIC TRANSMISSION 4X4 FIS SE BURNT ORANGE (A2006IBT4CUSK) - Cooling Assembly
2006 PROWLER XT 650 H1 AUTOMATIC 4X4 CAT GREEN (U2006P2S4BUSZ) - Cooling Assembly
2006 PROWLER XT 650 H1 AUTOMATIC 4X4 GREEN (U2006P2S4BUSG) - Cooling Assembly
2006 PROWLER XT 650 H1 AUTOMATIC 4X4 RED (U2006P2S4BUSR) - Cooling Assembly
2007 500 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2007IBM4BUSZ) - Cooling Assembly
2007 500 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2007IBM4BUSG) - Cooling Assembly
2007 500 AUTOMATIC TRANSMISSION 4X4 FIS GUN METAL BLUE (A2007IBM4BUSV) - Cooling Assembly
2007 500 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2007IBM4BUSR) - Cooling Assembly
2007 500 MANUAL TRANSMISSION 4X4 FIS CAT GREEN (A2007IBM4AUSZ) - Cooling Assembly
2007 500 MANUAL TRANSMISSION 4X4 FIS GREEN (A2007IBM4AUSG) - Cooling Assembly
2007 500 MANUAL TRANSMISSION 4X4 FIS RED (A2007IBM4AUSR) - Cooling Assembly
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS BLACK (A2007IBS4BUSP) - Cooling Assembly (Vin: 4Uf07atv17t236134 And Above)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS BLACK (A2007IBS4BUSP) - Cooling Assembly (Up To Vin: 4Uf07atv17t236134)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2007IBS4BUSZ) - Cooling Assembly (Up To Vin: 4Uf07atv17t236134)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2007IBS4BUSZ) - Cooling Assembly (Vin: 4Uf07atv17t236134 And Above)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2007IBS4BUSG) - Cooling Assembly (Vin: 4Uf07atv17t236134 And Above)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2007IBS4BUSG) - Cooling Assembly (Up To Vin: 4Uf07atv17t236134)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS GREEN LE (A2007IBS4BUSM) - Cooling Assembly (Vin: 4Uf07atv17t236134 And Above)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS GREEN LE (A2007IBS4BUSM) - Cooling Assembly (Up To Vin: 4Uf07atv17t236134)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS GUN METAL BLUE (A2007IBS4BUSV) - Cooling Assembly (Up To Vin: 4Uf07atv17t236134)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS GUN METAL BLUE (A2007IBS4BUSV) - Cooling Assembly (Vin: 4Uf07atv17t236134 And Above)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2007IBS4BUSC) - Cooling Assembly (Vin: 4Uf07atv17t236134 And Above)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2007IBS4BUSC) - Cooling Assembly (Up To Vin: 4Uf07atv17t236134)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2007IBS4BUSR) - Cooling Assembly (Vin: 4Uf07atv17t236134 And Above)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2007IBS4BUSR) - Cooling Assembly (Up To Vin: 4Uf07atv17t236134)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TBX GREEN (A2007BBS4BUSG) - Cooling Assembly (Up To Vin: 4Uf07atv17t236134)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TBX GREEN (A2007BBS4BUSG) - Cooling Assembly (Vin: 4Uf07atv17t236134 And Above)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TBX RED (A2007BBS4BUSR) - Cooling Assembly (Up To Vin: 4Uf07atv17t236134)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TBX RED (A2007BBS4BUSR) - Cooling Assembly (Vin: 4Uf07atv17t236134 And Above)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV BLACK LE (A2007TBS4BUSQ) - Cooling Assembly (Vin: 4Uf07atv17t236134 And Above)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV BLACK LE (A2007TBS4BUSQ) - Cooling Assembly (Up To Vin: 4Uf07atv17t236134)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2007TBS4BUSZ) - Cooling Assembly (Vin: 4Uf07atv17t236134 And Above)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2007TBS4BUSZ) - Cooling Assembly (Up To Vin: 4Uf07atv17t236134)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV GREEN (A2007TBS4BUSG) - Cooling Assembly (Vin: 4Uf07atv17t236134 And Above)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV GREEN (A2007TBS4BUSG) - Cooling Assembly (Up To Vin: 4Uf07atv17t236134)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2007TBS4BUSR) - Cooling Assembly (Up To Vin: 4Uf07atv17t236134)
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2007TBS4BUSR) - Cooling Assembly (Vin: 4Uf07atv17t236134 And Above)
2007 700 AUTOMATIC TRANSMISSION 4X4 DIESEL GREEN (A2007TBT4DUSG) - Cooling Assembly
2007 700 AUTOMATIC TRANSMISSION 4X4 DIESEL RED (A2007TBT4DUSR) - Cooling Assembly
2007 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2007IBT4CUSZ) - Cooling Assembly
2007 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2007IBT4CUSG) - Cooling Assembly

2007 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS GUN METAL BLUE (A2007IBT4CUSV) - Cooling Assembly
2007 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS ORANGE LE (A2007IBT4CUSK) - Cooling Assembly
2007 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS RED (A2007IBT4CUSR) - Cooling Assembly
2007 PROWLER 650 H1 AUTOMATIC 4X4 CAT GREEN (U2007P1S4BUSZ) - Cooling Assembly
2007 PROWLER 650 H1 AUTOMATIC 4X4 GREEN (U2007P1S4BUSG) - Cooling Assembly
2007 PROWLER 650 H1 AUTOMATIC 4X4 RED (U2007P1S4BUSR) - Cooling Assembly
2007 PROWLER XT 650 H1 AUTOMATIC 4X4 CAT GREEN (U2007P2S4BUSZ) - Cooling Assembly
2007 PROWLER XT 650 H1 AUTOMATIC 4X4 GREEN (U2007P2S4BUSG) - Cooling Assembly
2007 PROWLER XT 650 H1 AUTOMATIC 4X4 RED (U2007P2S4BUSR) - Cooling Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2008IBM4BUSZ) - Cooling Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2008IBM4BUSG) - Cooling Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBM4BUSC) - Cooling Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 FIS ORANGE LE (A2008IBM4BUSK) - Cooling Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2008IBM4BUSR) - Cooling Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2008TBM4BUSZ) - Cooling Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 TRV GREEN (A2008TBM4BUSG) - Cooling Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2008TBM4BUSR) - Cooling Assembly
2008 500 MANUAL TRANSMISSION 4X4 FIS GREEN (A2008IBM4AUSG) - Cooling Assembly
2008 500 MANUAL TRANSMISSION 4X4 FIS RED (A2008IBM4AUSR) - Cooling Assembly
2008 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS BLACK (A2008IBS4BUSP) - Cooling Assembly
2008 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2008IBS4BUSZ) - Cooling Assembly
2008 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2008IBS4BUSR) - Cooling Assembly
2008 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV BLACK (A2008TBS4BUSP) - Cooling Assembly
2008 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2008TBS4BUSZ) - Cooling Assembly
2008 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2008TBS4BUSR) - Cooling Assembly
2008 700 AUTOMATIC TRANSMISSION 4X4 DIESEL GREEN (A2008TBT4DUSG) - Cooling Assembly
2008 700 AUTOMATIC TRANSMISSION 4X4 DIESEL RED (A2008TBT4DUSR) - Cooling Assembly
2008 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2008IBT4CUSZ) - Cooling Assembly
2008 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2008IBT4CUSG) - Cooling Assembly
2008 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBT4CUSC) - Cooling Assembly
2008 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS ORANGE LE (A2008IBT4CUSK) - Cooling Assembly
2008 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS RED (A2008IBT4CUSR) - Cooling Assembly
2008 700 EFI AUTOMATIC TRANSMISSION 4X4 TRV CRUISER BLUE (A2008TCT4CUSV) - Cooling Assembly
2008 700 EFI AUTOMATIC TRANSMISSION 4X4 TRV LE BLACK (A2008TBT4CUSQ) - Cooling Assembly
2008 PROWLER 650 H1 AUTOMATIC 4X4 GREEN (U2008P1S4BUSG) - Cooling Assembly
2008 PROWLER XT 650 H1 AUTOMATIC 4X4 CAT GREEN (U2008P2S4BUSZ) - Cooling Assembly
2008 PROWLER XT 650 H1 AUTOMATIC 4X4 GREEN (U2008P2S4BUSG) - Cooling Assembly
2008 PROWLER XT 650 H1 AUTOMATIC 4X4 M4 CAMO (U2008P2S4BUSC) - Cooling Assembly
2008 PROWLER XT 650 H1 AUTOMATIC 4X4 RED (U2008P2S4BUSR) - Cooling Assembly
2009 500 4X4 AUTOMATIC GREEN (A2009IBM4BUSG) - Cooling Assembly
2009 500 4X4 AUTOMATIC RED (A2009IBM4BUSR) - Cooling Assembly
2009 500 4X4 MANUAL GREEN (A2009IBM4AUSG) - Cooling Assembly
2009 500 4X4 MANUAL RED (A2009IBM4AUSR) - Cooling Assembly
2009 650 TBX GREEN (A2009BBS4BUSG) - Cooling Assembly
2009 650 TRV CAT GREEN (A2009TBS4BUSZ) - Cooling Assembly
2009 PROWLER 650 XT AUTOMATIC 4X4 CAT GREEN (U2009P2S4BUSZ) - Cooling Assembly
2009 PROWLER 650 XT AUTOMATIC 4X4 GREEN (U2009P2S4BUSG) - Cooling Assembly
2009 PROWLER 650 XT AUTOMATIC 4X4 RED (U2009P2S4BUSR) - Cooling Assembly
2010 650 4X4 AUTOMATIC BLACK (A2010ICS4BUSP) - Cooling Assembly
2010 650 4X4 AUTOMATIC MUD PRO CAT GREEN (A2010IFS4BUSZ) - Cooling Assembly
2010 700 DIESEL BLACK (A2010TBT4DUSP) - Cooling Assembly
2011 650 H1 GREEN (A2011ICS4BUSG) - Cooling Assembly
2011 650 H1 MUD PRO CAT GREEN-BLACK (A2011IFS4BUSZ) - Cooling Assembly
2011 700 DIESEL GREEN (A2011TBT4DUSG) - Cooling Assembly
2012 650 RED (A2012ICS4BUSR) - Cooling Assembly
2012 700 DIESEL GREEN (A2012TBT4DUSG) - Cooling Assembly
2012 BEARCAT Z1 XT GS ORANGE (S2012BCNWGUSO) - Cooling Assembly
2013 700 DIESEL GREEN (A2013TBT4DUSG) - Cooling Assembly
2013 BEARCAT Z1 XT GS ORANGE (S2013BCNWGUSO) - Cooling Assembly
2014 700 DIESEL GREEN (A2014TBT4DUSG) - Cooling Assembly
2015 700 DIESEL GREEN (A2015TBT4DUSG) - Cooling Assembly