Dane aktualne na dzień: 05-11-2026 15:01

Link do produktu: https://www.moto-maniak.eu/przelacznik-zespolony-lewy-arctic-cat-400-500-700-1000-0509-014-p-12878.html



Przełącznik zespolony lewy arctic cat 400 500 700 1000 0509-014

Cena brutto	**195,00 zł**
Cena netto	**158,54 zł**
Dostępność	**Dostępny**
Numer katalogowy	**PRZ-A057**
Kod EAN	**5904858426270**
Producent	**X-ATV**

Opis produktu

Przełącznik zespolony lewy na kierownicę

zamiennik oem arctic cat : 0509-014

zastosowanie :

2004 500 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2004ISM4BUSZ) - Control Switch Housing Assembly
2004 500 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN MRP (A2004ISM4BUSV) - Control Switch Housing Assembly
2004 500 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2004ISM4BUSG) - Control Switch Housing Assembly
2004 500 AUTOMATIC TRANSMISSION 4X4 FIS GREEN MRP (A2004ISM4BUSS) - Control Switch Housing Assembly
2004 500 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2004ISM4BUSR) - Control Switch Housing Assembly
2004 500 AUTOMATIC TRANSMISSION 4X4 FIS RED MRP (A2004ISM4BUST) - Control Switch Housing Assembly
2004 500 AUTOMATIC TRANSMISSION 4X4 TBX GREEN (A2004BXM4BUSG) - Control Switch Housing Assembly
2004 500 AUTOMATIC TRANSMISSION 4X4 TBX RED (A2004BXM4BUSR) - Control Switch Housing Assembly
2004 500 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2004TDM4BUSZ) - Control Switch Housing Assembly
2004 500 AUTOMATIC TRANSMISSION 4X4 TRV GREEN (A2004TDM4BUSG) - Control Switch Housing Assembly
2004 500 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2004TDM4BUSR) - Control Switch Housing Assembly
2005 400 AUTOMATIC TRANSMISSION 4X4 FIS ADVANTAGE TIMBER CAMO (A2005ISH4BUSU) - Control Switch Housing Assembly
2005 400 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2005ISH4BUSJ) - Control Switch Housing Assembly
2005 400 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2005ISH4BUSH) - Control Switch Housing Assembly
2005 400 AUTOMATIC TRANSMISSION 4X4 FIS LE CAT GREEN (A2005ISH4BUSA) - Control Switch Housing Assembly
2005 400 AUTOMATIC TRANSMISSION 4X4 FIS LE GM CAMO (A2005ISH4BGMC) - Control Switch Housing Assembly
2005 400 AUTOMATIC TRANSMISSION 4X4 FIS LE GREEN (A2005ISH4BUSM) - Control Switch Housing Assembly
2005 400 AUTOMATIC TRANSMISSION 4X4 FIS LE RED (A2005ISH4BUSN) - Control Switch Housing Assembly
2005 400 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2005ISH4BUSI) - Control Switch Housing Assembly
2005 400 AUTOMATIC TRANSMISSION 4X4 GREEN (A2005ATH4BUSG) - Control Switch Housing Assembly
2005 400 AUTOMATIC TRANSMISSION 4X4 RED (A2005ATH4BUSR) - Control Switch Housing Assembly
2005 400 AUTOMATIC TRANSMISSION 4X4 TBX GREEN (A2005BBH4BUSG) - Control Switch Housing Assembly
2005 400 AUTOMATIC TRANSMISSION 4X4 TBX RED (A2005BBH4BUSR) - Control Switch Housing Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2005IBM4BUSZ) - Control Switch Housing Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2005IBM4BUSG) - Control Switch Housing Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 FIS LE CAT GREEN (A2005IBM4BUSA) - Control Switch Housing Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 FIS LE GREEN (A2005IBM4BUSM) - Control Switch Housing Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 FIS LE RED (A2005IBM4BUSN) - Control Switch Housing Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2005IBM4BUSR) - Control Switch Housing Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 TBX GREEN (A2005BBM4BUSG) - Control Switch Housing Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 TBX RED (A2005BBM4BUSR) - Control Switch Housing Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2005TDM4BUSZ) - Control Switch Housing Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 TRV GREEN (A2005TDM4BUSG) - Control Switch Housing Assembly
2005 500 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2005TDM4BUSR) - Control Switch Housing Assembly
2005 650 H1 4X4 BLACK LE (A2005IBS4BUSO) - Control Switch Housing Assembly

2006 400 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2006ICH4BUSZ) - Control Switch Housing Assembly
2006 400 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN LE (A2006ICH4BUSA) - Control Switch Housing Assembly
2006 400 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2006ICH4BUSG) - Control Switch Housing Assembly
2006 400 AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2006ICH4BUSC) - Control Switch Housing Assembly
2006 400 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2006ICH4BUSR) - Control Switch Housing Assembly
2006 400 AUTOMATIC TRANSMISSION 4X4 TBX GREEN (A2006BBH4BUSG) - Control Switch Housing Assembly
2006 400 AUTOMATIC TRANSMISSION 4X4 TBX RED (A2006BBH4BUSR) - Control Switch Housing Assembly
2006 400 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2006TBH4BUSZ) - Control Switch Housing Assembly
2006 400 AUTOMATIC TRANSMISSION 4X4 TRV GREEN (A2006TBH4BUSG) - Control Switch Housing Assembly
2006 400 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2006TBH4BUSR) - Control Switch Housing Assembly
2006 400 AUTOMATIC TRANSMISSION 4X4 VP GREEN (A2006ABH4BUSG) - Control Switch Housing Assembly
2006 400 AUTOMATIC TRANSMISSION 4X4 VP RED (A2006ABH4BUSR) - Control Switch Housing Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2006IBM4BUSZ) - Control Switch Housing Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2006IBM4BUSG) - Control Switch Housing Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2006IBM4BUSC) - Control Switch Housing Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2006IBM4BUSR) - Control Switch Housing Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 FIS RED LE (A2006IBM4BUSN) - Control Switch Housing Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 TBX GREEN (A2006BBM4BUSG) - Control Switch Housing Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 TBX RED (A2006BBM4BUSR) - Control Switch Housing Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2006TBM4BUSZ) - Control Switch Housing Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 TRV GREEN (A2006TBM4BUSG) - Control Switch Housing Assembly
2006 500 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2006TBM4BUSR) - Control Switch Housing Assembly
2006 650 H1 AUTOMATIC TRANSMISSION 4X4 BLACK SE (A2006IBS4BUSO) - Control Switch Housing Assembly
2006 650 H1 AUTOMATIC TRANSMISSION 4X4 BLACK SE CA (A2006IBS4BCAO) - Control Switch Housing Assembly
2006 700 AUTOMATIC TRANSMISSION 4X4 FIS SE BURNT ORANGE (A2006IBT4CUSK) - Control Switch Housing Assembly
2007 400 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2007ICH4BUSZ) - Control Switch Housing Assembly
2007 400 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2007ICH4BUSG) - Control Switch Housing Assembly
2007 400 AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2007ICH4BUSC) - Control Switch Housing Assembly
2007 400 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2007ICH4BUSR) - Control Switch Housing Assembly
2007 400 AUTOMATIC TRANSMISSION 4X4 FIS RED LE (A2007ICH4BUSN) - Control Switch Housing Assembly
2007 400 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2007TBH4BUSZ) - Control Switch Housing Assembly
2007 400 AUTOMATIC TRANSMISSION 4X4 TRV GREEN (A2007TBH4BUSG) - Control Switch Housing Assembly
2007 400 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2007TBH4BUSR) - Control Switch Housing Assembly
2007 500 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2007IBM4BUSZ) - Control Switch Housing Assembly
2007 500 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2007IBM4BUSG) - Control Switch Housing Assembly
2007 500 AUTOMATIC TRANSMISSION 4X4 FIS GUN METAL BLUE (A2007IBM4BUSV) - Control Switch Housing Assembly
2007 500 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2007IBM4BUSR) - Control Switch Housing Assembly
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS BLACK (A2007IBS4BUSP) - Control Switch Housing Assembly
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2007IBS4BUSZ) - Control Switch Housing Assembly
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2007IBS4BUSG) - Control Switch Housing Assembly
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS GREEN LE (A2007IBS4BUSM) - Control Switch Housing Assembly
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS GUN METAL BLUE (A2007IBS4BUSV) - Control Switch Housing Assembly
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2007IBS4BUSC) - Control Switch Housing Assembly
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2007IBS4BUSR) - Control Switch Housing Assembly
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TBX GREEN (A2007BBS4BUSG) - Control Switch Housing Assembly
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TBX RED (A2007BBS4BUSR) - Control Switch Housing Assembly
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV BLACK LE (A2007TBS4BUSQ) - Control Switch Housing Assembly
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2007TBS4BUSZ) - Control Switch Housing Assembly
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV GREEN (A2007TBS4BUSG) - Control Switch Housing Assembly
2007 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2007TBS4BUSR) - Control Switch Housing Assembly
2007 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2007IBT4CUSZ) - Control Switch Housing Assembly
2007 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2007IBT4CUSG) - Control Switch Housing Assembly
2007 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS GUN METAL BLUE (A2007IBT4CUSV) - Control Switch Housing Assembly
2007 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS ORANGE LE (A2007IBT4CUSK) - Control Switch Housing Assembly
2007 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS RED (A2007IBT4CUSR) - Control Switch Housing Assembly
2008 400 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2008ICH4BUSZ) - Control Switch Housing Assembly
2008 400 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2008ICH4BUSG) - Control Switch Housing Assembly
2008 400 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2008ICH4BUSR) - Control Switch Housing Assembly
2008 400 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2008TBH4BUSR) - Control Switch Housing Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2008IBM4BUSZ) - Control Switch Housing Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2008IBM4BUSG) - Control Switch Housing Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBM4BUSC) - Control Switch Housing Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 FIS ORANGE LE (A2008IBM4BUSK) - Control Switch Housing Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2008IBM4BUSR) - Control Switch Housing Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2008TBM4BUSZ) - Control Switch Housing Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 TRV GREEN (A2008TBM4BUSG) - Control Switch Housing Assembly
2008 500 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2008TBM4BUSR) - Control Switch Housing Assembly
2008 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS BLACK (A2008IBS4BUSP) - Control Switch Housing Assembly
2008 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2008IBS4BUSZ) - Control Switch Housing Assembly

2008 650 H1 AUTOMATIC TRANSMISSION 4X4 FIS RED (A2008IBS4BUSR) - Control Switch Housing Assembly
2008 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV BLACK (A2008TBS4BUSP) - Control Switch Housing Assembly
2008 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV CAT GREEN (A2008TBS4BUSZ) - Control Switch Housing Assembly
2008 650 H1 AUTOMATIC TRANSMISSION 4X4 TRV RED (A2008TBS4BUSR) - Control Switch Housing Assembly
2008 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS CAT GREEN (A2008IBT4CUSZ) - Control Switch Housing Assembly
2008 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS GREEN (A2008IBT4CUSG) - Control Switch Housing Assembly
2008 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS M4 CAMO (A2008IBT4CUSC) - Control Switch Housing Assembly
2008 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS ORANGE LE (A2008IBT4CUSK) - Control Switch Housing Assembly
2008 700 EFI AUTOMATIC TRANSMISSION 4X4 FIS RED (A2008IBT4CUSR) - Control Switch Housing Assembly
2008 700 EFI AUTOMATIC TRANSMISSION 4X4 TRV CRUISER BLUE (A2008TCT4CUSV) - Control Switch Housing Assembly
2008 700 EFI AUTOMATIC TRANSMISSION 4X4 TRV LE BLACK (A2008TBT4CUSQ) - Control Switch Housing Assembly
2008 700 H1 FEI AUTOMATIC TRANSMISSION 4X4 FIS SILVER SE (A2008IBT4EUSL) - Control Switch Housing Assembly
2008 THUNDERCAT AUTOMATIC TRANSMISSION 4X4 SILVER (A2008IEW4EUSL) - Control Switch Housing Assembly
2009 1000 TRV CRUISER SUNSET ORANGE (A2009TCW4EUSK) - Handlebar Assembly
2009 1000 TRV RED (A2009TBW4EUSR) - Handlebar Assembly
2009 400 TRV CAT GREEN (A2009TBG4BUSZ) - Handlebar Assembly
2009 400 TRV RED (A2009TBG4BUSR) - Handlebar Assembly
2009 500 4X4 AUTOMATIC GREEN (A2009IBM4BUSG) - Control Switch Housing Assembly
2009 500 4X4 AUTOMATIC RED (A2009IBM4BUSR) - Control Switch Housing Assembly
2009 550 H1 EFI 4X4 AUTOMATIC CAT GREEN (A2009IBO4EUSZ) - Handlebar Assembly
2009 550 H1 EFI 4X4 AUTOMATIC GREEN (A2009IBO4EUSG) - Handlebar Assembly
2009 550 H1 EFI 4X4 AUTOMATIC LE BLACK (A2009IBO4EUSQ) - Handlebar Assembly
2009 550 H1 EFI 4X4 AUTOMATIC M4 CAMO (A2009IBO4EUSC) - Handlebar Assembly
2009 550 H1 EFI 4X4 AUTOMATIC RED (A2009IBO4EUSR) - Handlebar Assembly
2009 550 TRV LE BLACK (A2009TBO4EUSQ) - Handlebar Assembly
2009 550 TRV RED (A2009TBO4EUSR) - Handlebar Assembly
2009 550 TRV STEEL BLUE (A2009TBO4EUSV) - Handlebar Assembly
2009 650 TBX GREEN (A2009BBS4BUSG) - Handlebar Assembly
2009 650 TRV CAT GREEN (A2009TBS4BUSZ) - Handlebar Assembly
2009 700 H1 EFI 4X4 AUTOMATIC CAT GREEN (A2009IBT4EUSZ) - Handlebar Assembly
2009 700 H1 EFI 4X4 AUTOMATIC GREEN (A2009IBT4EUSG) - Handlebar Assembly
2009 700 H1 EFI 4X4 AUTOMATIC LE BLACK (A2009IBT4EUSQ) - Handlebar Assembly
2009 700 H1 EFI 4X4 AUTOMATIC M4 CAMO (A2009IBT4EUSC) - Handlebar Assembly
2009 700 H1 EFI 4X4 AUTOMATIC MUD PRO METALLIC CAT GREEN (A2009IFT4EUSZ) - Handlebar Assembly
2009 700 H1 EFI 4X4 AUTOMATIC RED (A2009IBT4EUSR) - Handlebar Assembly
2009 700 H1 EFI 4X4 AUTOMATIC SILVER SE (A2009IBT4EUSL) - Handlebar Assembly
2009 700 TRV CRUISER STEEL BLUE (A2009TCT4EUSV) - Handlebar Assembly
2009 THUNDERCAT EFI 4X4 AUTO FIS SE SILVER (A2009IEW4EUSL) - Handlebar Assembly
2010 1000 4X4 AUTOMATIC MUD PRO WHITE (A2010IFW4EUSW) - Handlebar Assembly
2010 400 TRV BLACK (A2010TBG4BUSP) - Handlebar Assembly
2010 450 EFI CAT GREEN (A2010ICK4CUSZ) - Handlebar Assembly
2010 450 EFI GREEN (A2010ICK4CUSG) - Handlebar Assembly
2010 450 EFI RED (A2010ICK4CUSR) - Handlebar Assembly
2010 550 H1 EFI 4X4 AUTOMATIC GREEN (A2010ICO4EUSG) - Handlebar Assembly
2010 550 H1 EFI 4X4 AUTOMATIC METALLIC CAT GREEN (A2010ICO4EUSM) - Handlebar Assembly
2010 550 H1 EFI 4X4 AUTOMATIC TIMBER CAMO (A2010ICO4EUSH) - Handlebar Assembly
2010 550 TRV GREEN (A2010TBO4EUSG) - Handlebar Assembly
2010 550 TRV METALLIC BLACK (A2010TBO4EUSO) - Handlebar Assembly
2010 550s H1 EFI METALLIC GRAY (A2010ICO1PUSS) - Handlebar Assembly
2010 550s H1 EFI RED (A2010ICO1PUSR) - Handlebar Assembly
2010 650 4X4 AUTOMATIC BLACK (A2010ICS4BUSP) - Handlebar Assembly
2010 650 4X4 AUTOMATIC MUD PRO CAT GREEN (A2010IFS4BUSZ) - Handlebar Assembly
2010 700 H1 EFI 4X4 AUTOMATIC METALLIC CAT GREEN (A2010IBT4EUSM) - Handlebar Assembly
2010 700 H1 EFI 4X4 AUTOMATIC MUD PRO METALLIC CAT GREEN (A2010IFT4EUSA) - Handlebar Assembly
2010 700 H1 EFI 4X4 AUTOMATIC RED (A2010IBT4EUSR) - Handlebar Assembly
2010 700 H1 EFI 4X4 AUTOMATIC TIMBER CAMO (A2010IBT4EUSH) - Handlebar Assembly
2010 700 H1 EFI 4X4 TBX BLACK (A2010BBT4EUSP) - Handlebar Assembly
2010 700 TRV CRUISER SUNSET ORANGE (A2010TCT4EUSU) - Handlebar Assembly
2010 700 TRV METALLIC BLACK (A2010TBT4EUSO) - Handlebar Assembly
2010 700s H1 EFI GREEN (A2010IBT1PUSG) - Handlebar Assembly
2010 700s H1 EFI LE BLUE (A2010IBT1PUSB) - Handlebar Assembly
2010 THUNDERCAT EFI 4X4 METALLIC BLACK (A2010IEW4EUSO) - Handlebar Assembly
2010 THUNDERCAT EFI 4X4 METALLIC CAT GREEN (A2010IEW4EUSM) - Handlebar Assembly
2010 TRV 1000 CRUISER DESERT RED (A2010TCW4EUSI) Desert Red - Handlebar Assembly
2010 TRV 1000 CRUISER METALLIC CAT GREEN (A2010TCW4EUSA) Metallic Cat Green - Handlebar Assembly
2010 TRV 1000 METALLIC BLACK (A2010TBW4EUSO) Metallic Black - Handlebar Assembly
2010 TRV 550s H1 EFI BLUE (A2010TBO1PUSD) - Handlebar Assembly
2010 TRV 700s H1 EFI METALLIC GRAY (A2010TBT1PUSS) - Handlebar Assembly
2011 1000 H2 EFI MUD PRO GREEN-BLACK (A2011IFW4EUSM) - Handlebar Assembly

2011 1000s H2 EFI GREEN-BLACK (A2011IEW1PUSM) - Handlebar Assembly
2011 450 EFI CAT GREEN (A2011ICK4CUSZ) - Handlebar Assembly
2011 450 EFI GREEN (A2011ICK4CUSG) - Handlebar Assembly
2011 450 EFI METALLIC GRAY (A2011ICK4CUSS) - Handlebar Assembly
2011 450 EFI RED (A2011ICK4CUSR) - Handlebar Assembly
2011 450 EFI TIMBER CAMO (A2011ICK4CUSH) - Handlebar Assembly
2011 550 H1 EFI GREEN (A2011ICO4EUSG) - Handlebar Assembly
2011 550 H1 EFI RED (A2011ICO4EUSR) - Handlebar Assembly
2011 550 H1 EFI TIMBER CAMO (A2011ICO4EUSH) - Handlebar Assembly
2011 550s H1 EFI CAT GREEN (A2011ICO1PUSZ) - Handlebar Assembly
2011 550s H1 EFI GREEN (A2011ICO1PUSG) - Handlebar Assembly
2011 550s H1 EFI LTD METALLIC GRAY (A2011ICO1PUSS) - Handlebar Assembly
2011 650 H1 GREEN (A2011ICS4BUSG) - Handlebar Assembly
2011 650 H1 MUD PRO CAT GREEN-BLACK (A2011IFS4BUSZ) - Handlebar Assembly
2011 700 H1 EFI CAT GREEN (A2011IBT4EUSZ) - Handlebar Assembly
2011 700 H1 EFI GREEN (A2011IBT4EUSG) - Handlebar Assembly
2011 700 H1 EFI MUD PRO GREEN-BLACK (A2011IFT4EUSM) - Handlebar Assembly
2011 700 H1 EFI MUD PRO ORANGE-BLACK (A2011IFT4EUSY) - Handlebar Assembly
2011 700s H1 EFI BLACK (A2011IBT1PUSP) - Handlebar Assembly
2011 700s H1 EFI BLUE (A2011IBT1PUSB) - Handlebar Assembly
2011 700s H1 EFI METALLIC GRAY (A2011IBT1PUSS) - Handlebar Assembly
2011 700s H1 EFI TBX METALLIC CAT GREEN (A2011BBT1PUSA) - Handlebar Assembly
2011 700s H1 EFI TIMBER CAMO (A2011IBT1PUSH) - Handlebar Assembly
2011 700s TRV CRUISER METALLIC GRAY (A2011TCT1PUSS) - Handlebar Assembly
2011 TRV 1000s CRUISER BLUE (A2011TCW1PUSD) - Handlebar Assembly
2011 TRV 400 RED (A2011TBG4BUSR) - Handlebar Assembly
2011 TRV 450 EFI RED (A2011TBK4CUSR) - Handlebar Assembly
2011 TRV 550 H1 EFI CAT GREEN (A2011TBO4EUSZ) - Handlebar Assembly
2011 TRV 550s H1 EFI CRUISER BLUE (A2011TCO1PUSD) - Handlebar Assembly
2011 TRV 550s H1 EFI GT COPPER (A2011TBO1PUSX) - Handlebar Assembly
2011 TRV 700 RED (A2011TBT4EUSR) - Handlebar Assembly
2011 TRV 700s H1 EFI METALLIC CAT GREEN (A2011TBT1PUSA) - Handlebar Assembly
2012 1000 GT ORANGE-BLACK (A2012AGW1PUSY) - Handlebar Assembly
2012 1000 MUD PRO LTD BLACK-ORANGE (A2012MLW1PUSY) - Handlebar Assembly
2012 450 GREEN (A2012ICK4CUSG) - Handlebar Assembly
2012 450 GT BLUE (A2012BGK2PUSD) - Handlebar Assembly
2012 450 GT ORANGE (A2012BGK2PUSU) - Handlebar Assembly
2012 450 RED (A2012ICK4CUSR) - Handlebar Assembly
2012 450 TIMBER CAMO (A2012ICK4CUSH) - Handlebar Assembly
2012 550 BLACK (A2012ICO4EUSP) - Handlebar Assembly
2012 550 GREEN (A2012ICO4EUSG) - Handlebar Assembly
2012 550 GT ORANGE (A2012BGO1PUSU) - Handlebar Assembly
2012 550 GT STEEL BLUE (A2012BGO1PUSV) - Handlebar Assembly
2012 550 GT TIMBER CAMO (A2012BGO1PUSH) - Handlebar Assembly
2012 550 LTD DESERT RED (A2012BLO1PUSI) - Handlebar Assembly
2012 550 LTD METALLIC GREEN (A2012BLO1PUSA) - Handlebar Assembly
2012 650 RED (A2012ICS4BUSR) - Handlebar Assembly
2012 700 GT BLUE (A2012AGT1PUSD) - Handlebar Assembly
2012 700 GT METALLIC GRAY (A2012AGT1PUSS) - Handlebar Assembly
2012 700 GT TIMBER CAMO (A2012AGT1PUSH) - Handlebar Assembly
2012 700 LTD METALLIC GREEN (A2012ALT1PUSA) - Handlebar Assembly
2012 700 MUD PRO LTD METALLIC GREEN (A2012MLT1PUSA) - Handlebar Assembly
2012 700 MUD PRO LTD ORANGE (A2012MLT1PUSY) - Handlebar Assembly
2012 700 MUD PRO METALLIC GREEN (A2012IFT4EUSA) - Handlebar Assembly
2012 700 RED (A2012IBT4EUSR) - Handlebar Assembly
2012 TBX 700 GT METALLIC GRAY (A2012BCT1PUSS) - Handlebar Assembly
2012 TRV 1000 CRUISER METALLIC GRAY (A2012TCW1PUSS) - Handlebar Assembly
2012 TRV 1000 GT METALLIC GREEN (A2012TGW1PUSA) - Handlebar Assembly
2012 TRV 400 RED (A2012TBG4BUSR) - Handlebar Assembly
2012 TRV 450 BLACK (A2012TBK4CUSP) - Handlebar Assembly
2012 TRV 450 GT ORANGE (A2012TGK2PUSU) - Handlebar Assembly
2012 TRV 550 CRUISER METALLIC GRAY (A2012TCO1PUSS) - Handlebar Assembly
2012 TRV 550 CRUISER METALLIC GREEN (A2012TCO1PUSA) - Handlebar Assembly
2012 TRV 550 GT BLUE (A2012TGO1PUSD) - Handlebar Assembly
2012 TRV 550 GT ORANGE (A2012TGO1PUSU) - Handlebar Assembly
2012 TRV 700 CRUISER ORANGE (A2012TCT1PUSU) - Handlebar Assembly
2012 TRV 700 CRUISER STEEL BLUE (A2012TCT1PUSV) - Handlebar Assembly
2012 TRV 700 GT BLUE (A2012TGT1PUSD) - Handlebar Assembly
2012 TRV 700 GT ORANGE (A2012TGT1PUSU) - Handlebar Assembly

2013 1000 MUD PRO METALLIC GREEN (A2013MLW1PUSN) - Handlebar Assembly
2013 1000 XT WHITE-BLACK (A2013AGW1PUSW) - Handlebar Assembly
2013 500 GREEN (A2013ICK4CUSG) - Handlebar Assembly
2013 500 RED (A2013ICK4CUSR) - Handlebar Assembly
2013 500 XT BLUE (A2013BSK4CUSD) - Handlebar Assembly
2013 500 XT CAMO (A2013BSK4CUSH) - Handlebar Assembly
2013 550 GREEN (A2013ICO4EUSG) - Handlebar Assembly
2013 550 LIMITED CAMO (A2013BLO1PUSH) - Handlebar Assembly
2013 550 LIMITED DESERT RED (A2013BLO1PUSI) - Handlebar Assembly
2013 550 LIMITED STEEL BLUE (A2013BLO1PUSV) - Handlebar Assembly
2013 550 XT METALLIC GREEN (A2013BGO1PUSN) - Handlebar Assembly
2013 550 XT ORANGE (A2013BGO1PUSU) - Handlebar Assembly
2013 700 GREEN (A2013IBT4EUSG) - Handlebar Assembly
2013 700 LTD METALLIC GREEN (A2013ALT1PUSA) - Handlebar Assembly
2013 700 LTD TIMBER CAMO (A2013ALT1PUSH) - Handlebar Assembly
2013 700 MUD PRO METALLIC CAT GREEN (A2013MLT1PUST) - Handlebar Assembly
2013 700 MUD PRO METALLIC GREEN (A2013MLT1PUSA) - Handlebar Assembly
2013 700 RED (A2013IBT4EUSR) - Handlebar Assembly
2013 700 XT ORANGE (A2013AGT1PUSU) - Handlebar Assembly
2013 700 XT STEEL BLUE (A2013AGT1PUSV) - Handlebar Assembly
2013 TBX 700 METALLIC GREEN (A2013BCT1PUSN) - Handlebar Assembly
2013 TRV 1000 LTD METALLIC GRAY (A2013TCW1PUSS) - Handlebar Assembly
2013 TRV 400 BLACK (A2013TBG4BUSP) - Handlebar Assembly
2013 TRV 500 RED (A2013TBK4CUSR) - Handlebar Assembly
2013 TRV 550 LTD METALLIC GRAY (A2013TCO1PUSS) - Handlebar Assembly
2013 TRV 550 XT METALLIC GREEN (A2013TGO1PUSN) - Handlebar Assembly
2013 TRV 700 LTD METALLIC BLACK (A2013TCT1PUSQ) - Handlebar Assembly
2013 TRV 700 XT DESERT RED (A2013TGT1PUSI) - Handlebar Assembly
2014 1000 MUD PRO LTD GREEN-BLACK (A2014MLW1PUSX) - Handlebar Assembly
2014 1000 XT GREEN-BLACK (A2014AGW1PUSX) - Handlebar Assembly
2014 500 GREEN (A2014ICK4CUSG) - Handlebar Assembly
2014 500 RED (A2014ICK4CUSR) - Handlebar Assembly
2014 500 XT ORANGE (A2014BSK4CUSU) - Handlebar Assembly
2014 500 XT TIMBER CAMO (A2014BSK4CUSH) - Handlebar Assembly
2014 550 LTD GREEN (A2014BLO1PUSX) - Handlebar Assembly
2014 550 LTD RED (A2014BLO1PUSE) - Handlebar Assembly
2014 550 LTD TIMBER CAMO (A2014BLO1PUSH) - Handlebar Assembly
2014 550 RED (A2014ICO4EUSR) - Handlebar Assembly
2014 550 XT BLUE (A2014BGO1PUSD) - Handlebar Assembly
2014 550 XT GRAY (A2014BGO1PUSS) - Handlebar Assembly
2014 700 GREEN (A2014IBT4EUSG) - Handlebar Assembly
2014 700 LTD METALLIC BLUE (A2014ALT1PUSD) - Handlebar Assembly
2014 700 LTD METALLIC RED (A2014ALT1PUSE) - Handlebar Assembly
2014 700 LTD TIMBER CAMO (A2014ALT1PUSH) - Handlebar Assembly
2014 700 MUD PRO LTD GREEN-BLACK (A2014MLT1PUSX) - Handlebar Assembly
2014 700 MUD PRO LTD RED-BLACK (A2014MLT1PUSE) - Handlebar Assembly
2014 700 RED (A2014IBT4EUSR) - Handlebar Assembly
2014 700 XT BLUE (A2014AGT1PUSL) - Handlebar Assembly
2014 700 XT GREEN (A2014AGT1PUSX) - Handlebar Assembly
2014 TBX 700 RED (A2014BBT4EUSR) - Handlebar Assembly
2014 TRV 1000 LTD BLUE (A2014TCW1PUSL) - Handlebar Assembly
2014 TRV 400 RED (A2014TBG4BUSR) - Handlebar Assembly
2014 TRV 500 GREEN (A2014TBK4CUSG) - Handlebar Assembly
2014 TRV 500 RED (A2014TBK4CUSR) - Handlebar Assembly
2014 TRV 550 LTD BLUE (A2014TCO1PUSL) - Handlebar Assembly
2014 TRV 550 LTD ORANGE (A2014TCO1PUSU) - Handlebar Assembly
2014 TRV 550 XT GREEN (A2014TGO1PUSX) - Handlebar Assembly
2014 TRV 550 XT RED (A2014TGO1PUSE) - Handlebar Assembly
2014 TRV 700 LTD BLUE (A2014TCT1PUSL) - Handlebar Assembly
2014 TRV 700 LTD GREEN (A2014TCT1PUSN) - Handlebar Assembly
2014 TRV 700 XT BLUE (A2014TGT1PUSD) - Handlebar Assembly
2014 TRV 700 XT GREEN (A2014TGT1PUSX) - Handlebar Assembly
2015 1000 MUD PRO LTD BLACK (A2015MLW1PUSJ) - Handlebar Assembly
2015 1000 XT RED (A2015AGW1PUSE) - Handlebar Assembly
2015 500 GREEN (A2015ICK4CUSG) - Handlebar Assembly
2015 500 RED (A2015ICK4CUSR) - Handlebar Assembly
2015 700 MUD PRO LTD BLACK (A2015MLT1PUSJ) - Handlebar Assembly
2015 700 TBX RED (A2015BBT1PUSR) - Handlebar Assembly
2015 TRV 1000 LTD BLUE (A2015TCW1PUSD) - Handlebar Assembly

2015 TRV 1000 XT BLUE (A2015TGW1PUSL) - Handlebar Assembly
2015 TRV 1000 XT ORANGE (A2015TGW1PUSU) - Handlebar Assembly
2015 TRV 500 GREEN (A2015TBK4CUSZ) - Handlebar Assembly
2015 TRV 500 RED (A2015TBK4CUSR) - Handlebar Assembly
2015 TRV 550 LTD BLUE (A2015TCO1PUSV) - Handlebar Assembly
2015 TRV 550 LTD RED (A2015TCO1PUSE) - Handlebar Assembly
2015 TRV 550 XT BLUE (A2015TGO1PUSL) - Handlebar Assembly
2015 TRV 550 XT ORANGE (A2015TGO1PUSU) - Handlebar Assembly
2015 TRV 700 LTD ORANGE (A2015TCT1PUSU) - Handlebar Assembly
2015 TRV 700 LTD RED (A2015TCT1PUSE) - Handlebar Assembly
2015 TRV 700 XT BLUE (A2015TGT1PUSL) - Handlebar Assembly
2015 TRV 700 XT ORANGE (A2015TGT1PUSU) - Handlebar Assembly
2015 XR 500 GREEN (A2015XAK4CUSG) - Handlebar Assembly
2015 XR 500 RED (A2015XAK4CUSR) - Handlebar Assembly
2015 XR 550 GREEN (A2015XAO4EUSG) - Handlebar Assembly
2015 XR 700 GREEN (A2015XAT4EUSG) - Handlebar Assembly
2016 1000 MUD PRO SE EPS (A2016MLW1PUSW) - Handlebar Assembly
2016 1000 XT GREEN (A2016AGW1PUSX) - Handlebar Assembly
2016 500 GREEN (A2016ICK4CUSG) - Handlebar Assembly
2016 500 RED (A2016ICK4CUSR) - Handlebar Assembly
2016 700 MUD PRO LTD GREEN (A2016MLT1PUSJ) - Handlebar Assembly
2016 ALTERRA 550 RED (A2016XAO4EUSR) - Handlebar Assembly
2016 ALTERRA 700 RED (A2016XAT4EUSR) - Handlebar Assembly
2016 TBX 700 EPS RED (A2016BBT1PUSR) - Handlebar Assembly
2016 TBX 700 EPS SE CAMO/ORANGE (A2016BBT1PUSH) - Handlebar Assembly
2016 TRV 700 EPS SE BLACK (A2016TCT1PUSP) - Handlebar Assembly
2016 TRV 700 EPS SE CAMO/ORANGE (A2016TCT1PUSH) - Handlebar Assembly
2017 1000 MUD PRO LTD EPS BLACK (A2017MLW1PUSP) - Handlebar Assembly
2017 1000 XT EPS WHITE (A2017AGW1PUSW) - Handlebar Assembly
2017 500 GREEN (A2017ICK4CUSG) - Handlebar Assembly
2017 500 RED (A2017ICK4CUSR) - Handlebar Assembly
2017 700 MUD PRO LTD EPS BLACK (A2017MLT1PUSP) - Handlebar Assembly
2017 ALTERRA 700 RED (A2017XAT4EUSR) - Handlebar Assembly
2017 ALTERRA TRV 500 GREEN (A2017THK4CUSZ) - Handlebar Assembly
2017 ALTERRA TRV 500 RED (A2017THK4CUSR) - Handlebar Assembly
2017 TBX 700 EPS RED (A2017BAT1PUSR) - Handlebar Assembly
2017 VLX 700 BLACK (A2017IBT4EUSP) - Handlebar Assembly
2017 VLX 700 CAMO (A2017IBT4EUSH) - Handlebar Assembly
2018 ALTERRA 700 MUD PRO LTD EPS GRAY (A2018MLT1PUSI) - Handlebar Assembly
2018 ALTERRA 700 RED (A2018XAT4EUSR) - Handlebar Assembly
2018 ALTERRA TBX 700 EPS BLACK (A2018BAT1PUSP) - Handlebar Assembly
2018 ALTERRA VLX 700 BLACK (A2018IBT4EUSP) - Handlebar Assembly
2018 ALTERRA VLX 700 CAMO (A2018IBT4EUSH) - Handlebar Assembly
2018 ALTERRA VLX 700 EPS BLACK (A2018IBT1PUSP) - Handlebar Assembly
2018 ALTERRA VLX 700 EPS CAMO (A2018IBT1PUSH) - Handlebar Assembly
2019 ALTERRA 570 EPS CAMO (A2019XEO1PUSH) - Handlebar Assembly
2019 ALTERRA 570 EPS CHARCOAL (A2019XEO1PUSD) - Handlebar Assembly
2019 ALTERRA 570 GRAY (A2019XAO4EUSI) - Handlebar Assembly
2019 ALTERRA 570 XT EPS RED (A2019XCO1PUSM) - Handlebar Assembly
2019 ALTERRA 700 EPS BLUE (A2019XET1PUSE) - Handlebar Assembly
2019 ALTERRA 700 EPS CAMO (A2019XET1PUSH) - Handlebar Assembly
2019 ALTERRA 700 GRAY (A2019XAT4EUSI) - Handlebar Assembly
2019 ALTERRA 700 MUD PRO LTD EPS BLUE (A2019MLT1PUSE) - Handlebar Assembly
2019 ALTERRA 700 XT EPS RED (A2019XCT1PUSM) - Handlebar Assembly
2019 ALTERRA TBX 700 EPS GRAY (A2019BAT1PUSI) - Handlebar Assembly
2020 ALTERRA 570 DYNAMIC CHARCOAL (A2020XAO4EUSD) - Handlebar Assembly
2020 ALTERRA 570 DYNAMIC GRAY (A2020XAO4EUSI) - Handlebar Assembly
2020 ALTERRA 570 EPS BLACK (A2020XEO4PUSP) - Handlebar Assembly
2020 ALTERRA 570 EPS DYNAMIC CHARCOAL (A2020XCO4EUSD) - Handlebar Assembly
2020 ALTERRA 570 EPS GREEN (A2020XEO4PUSG) - Handlebar Assembly
2020 ALTERRA 570 EPS RED (A2020XEO4PUSM) - Handlebar Assembly
2020 ALTERRA 700 EPS BLACK (A2020XET4PUSP) - Handlebar Assembly
2020 ALTERRA 700 EPS DYNAMIC CHARCOAL (A2020XCT4EUSD) - Handlebar Assembly
2020 ALTERRA 700 EPS GREEN (A2020XET4PUSG) - Handlebar Assembly
2020 ALTERRA 700 EPS RED (A2020XET4PUSM) - Handlebar Assembly
2020 ALTERRA TBX 700 EPS DYNAMIC GRAY (A2020BAT1PUSI) - Handlebar Assembly
2020 ALTERRA TRV 500 BLUE (A2020THK4CUSE) - Handlebar Assembly
2020 ALTERRA TRV 500 RED (A2020THK4CUSM) - Handlebar Assembly
2021 ALTERRA 570 EPS DYNAMIC CHARCOAL (A2021XEO1PUSD) - Handlebar Assembly

2021 ALTERRA 570 SE EPS BLUE (A2021XDO4PUSE) - Handlebar Assembly
2021 ALTERRA 700 EPS BLUE (A2021XET4PUSE) - Handlebar Assembly
2021 ALTERRA 700 SE EPS BLUE (A2021XDT4PUSE) - Handlebar Assembly
2022 ALTERRA 600 EPS GREEN (A2022XKQ2PUSB) - Handlebar Assembly
2022 ALTERRA 600 XT EPS CA PHANTOM GRAY (A2022XMQ2PCAU) - Handlebar Assembly
2022 ALTERRA 600 XT EPS PHANTOM GRAY (A2022XMQ2PUSU) - Handlebar Assembly
2023 ALTERRA 600 EPS 49 GREEN (A2023XKQ2PUSB) - Handlebar Assembly
2023 ALTERRA 600 EPS 50 GREEN (A2023XKQ2PCAB) - Handlebar Assembly
2023 ALTERRA 600 EPS BLACK HILLS 49 WHITE (A2023XSQ2PUSW) - Handlebar Assembly
2023 ALTERRA 600 TRV EPS 49 GREEN (A2023TRQ2PUSB) - Handlebar Assembly
2023 ALTERRA 600 TRV EPS 50 GREEN (A2023TRQ2PCAB) - Handlebar Assembly
2023 ALTERRA 600 TRV XT EPS 49 PHANTOM GRAY (A2023TSQ2PUSU) - Handlebar Assembly
2023 ALTERRA 600 XT EPS 49 PHANTOM GRAY (A2023XMQ2PUSU) - Handlebar Assembly
2023 ALTERRA 600 XT EPS 50 PHANTOM GRAY (A2023XMQ2PCAU) - Handlebar Assembly